



Velvet Drive[®] Marine Installation Manual



Mercury **Out**

Mercury Marine Corporation



Velvet Drive[®]

Marine Installation Manual



Only Motor with "Velvet"

Reduction Gear, No. 2
No. 2000-13000

500-010-000

Water Gear

Westerbeke Engine Company
10000 West 100th Street
Minnetonka, Minnesota 55342



TABLE OF CONTENTS

FOREWORD	1
INDEX TO "I" AND "II" SERVICE INSTRUCTIONS	2
SELECTING A PROPER VELVET DRIVE	3
PROPELLER SELECTION	4
INSTALLATION DRAWING FOR IN-LINE TRANSMISSIONS	5
CHART SHOWING IN-LINE NOZZLE AND MISCELLANEOUS DATA	6
INSTALLATION DRAWING FOR V-DRIVE TRANSMISSIONS	7
CHART SHOWING V-DRIVE NOZZLE AND MISCELLANEOUS DATA	8
INSTALLATION DRAWING FOR DROP CENTER TRANSMISSIONS	9
CHART SHOWING DROP CENTER NOZZLE AND MISCELLANEOUS DATA	10
ADAPTER MOUNTING	11
TRANSMISSION INSTALLATION	12
TYPICAL INSTALLATIONS SHOWN PICTORIAL	13
TRANSMISSION OPERATION	14
PROPELLER SHAFT COMPONENTS	15
COVERS	16
CONNECTING CABLE TO TRANSMISSION	17
VEHICLE SHIMMING	18
CAUTION APPLICATION CHART	19
CAUTION INSTALLATION	20
BEFORE SAFETY SWITCH	21
ROUTINE CHECK AND MAINTENANCE	22
MATCHING ENGINE, TRANSMISSION AND PROPELLER RATION	23

FOREWORD

This manual covers all Volvo Drive[®] excavators. It is given to guide you in selecting the proper excavator, under-
stand its use and provide safety reading. Proper installation is a requirement for a valid warranty. Instructions for making
a proper installation are included. Better service and extended product life can be expected when the recommended com-
ponents are used and properly installed.

THIS CHART HAS BEEN ADDED TO HELP IDENTIFY EARLY VEGET DRIVE ASSEMBLIES.

The following are identification markings for Volvo Drive Motor/Drive Units:

MODEL NO. L.C. NO.†	MODEL NO. L.C. NO.	MODEL NO. L.C. NO.	POWER kW/HP	TYPE OF MOTOR/DRIVE
0	1	2	0.9kW	Roller
04	04	04	1.020kW/1	Roller
06	06	06	2.190kW/1	Counterbalance
06A	06A	06A	2.190kW/1	Counterbalance
08	08	08	2.675kW/1	Roller
09	11	07	2.680kW/1	Roller

† These numbers are stamped on serial number plates preceding the serial numbers.

10-17 & 10-18 UNITS

The 1:1 ratio units in the 10-17 and 10-18 series are identical except for the sumpleam to the 71C and 72C units which they replace. The sumpleam was changed to be consistent with reduction units of these models.

The forward and bearing portion of the reduction units of the 10-17 and 10-18 units is the same as the 71C and 72C units which they replaced. The reduction portion of the 10-17 and 10-18 units was changed to include a compression space between the two tapered bearing components. Tightening the coupling nut causes the shims to be compressed, allowing the tapered bearing to be preloaded. A bearing retainer is not used and the rear oil seal is pressed into the reduction housing.

The reduction gear is placed in the housing of 71C and 72C 1.5:1 units. The wrap ring holds the rear gear in an adapter plate which is bolted to the reduction housing of 10-17 and 10-18 reduction units. An oil baffle is bolted to the reduction of 2.0:1 and 2.5:1 reduction units of the 10-17 and 10-18 series transmissions.

— IMPORTANT —

MODELS 10-17 AND 10-18 (SERVO) INSTRUCTIONS

Practically all information which has been advised for the 71C and 72C (Other transmissions applied to the 10-17 and 10-18 assemblies. Use the appropriate instructions given in the 71C and 72C service manuals when assembling the 10-17 and 10-18 transmissions. The instructions given below for assembling the bearing and output shaft into the reduction housing.

Press two bearing caps into the reduction housing. Press rear bearing cone into the rear bearing cup. Press the oil seal into the reduction housing until rear face of oil seal is flush with rear face of bore in housing. Press the front bearing cone over output shaft and against face of shaft. Assemble the bearing shims over shaft and against cone. Lower the reduction housing over shaft components. Clean lips of oil seal and install the coupling end nut to the output shaft.

Locate reduction housing and attached parts on a suitable block placed under the center or other parts attached to the output shaft so that the reduction housing can be rotated as the coupling nut is being tightened. A tool should be used to hold the coupling while the output shaft nut is being tightened. A helper should rotate the reduction housing and the coupling nut should be tightened until an increase in effort required to turn the reduction housing is noted.

Use the reduction housing on its side and use a torque wrench to turn the output shaft through the housing to check the bearing cup seated by the housing being preloaded. A maximum of 45 ft-lb (61.1 Nm) but preferably 30 to 35 ft-lb (40.7 to 47.4 Nm) torque should be required to rotate the output shaft through the oil seal and properly preloaded bearing. A non bearing grease should always be used after the output shaft nut has been loosened after being properly preloaded. If the spacer must be reused, always go to a slightly higher preload than the amount had been torqued to previously.

IMPORTANT — SEE LATE BULLETINS ON THESE MODELS.

SELECTING A PROPER VELVET DRIVE

Optimum performance can only be obtained when all components are properly selected for the application. Applications having components which are excellent for a particular use may be completely unsuitable for another use. Best considerations for component selection are discussed in this manual. Specific information is given for the various Velvet Drive models. Reference to various Drive will be made to help you find information which is not included.

ENGINE ROTATION

Transmission selection will be simplified when the following method is used to describe engine rotation. This method does not agree with the engine manufacturer for the selling engine rotation.

Face the end of the engine on which the transmission is mounted and describe rotation as clockwise if the engine rotates clockwise. Describe the engine rotation as counter-rotating if the engine rotates counterclockwise.

TRANSMISSION ROTATION

Describe transmission input and output shaft rotation as clockwise or counterclockwise/counterclockwise when standing behind the transmission looking forward therein into or engine end of the transmission.

All Velvet Drive units except the 11B11 In-Line and CR2 units may be used behind engines having either rotation; however, the pump must be indexed for the desired rotation. The reduction and planetary carrier is different for opposite rotating 2.1 & 1 In-Line units and early models will occur on these units if they are driven in the wrong direction.

The output shaft rotates in the same direction or in the opposite direction to the input shaft depending upon the transmission assembly; therefore, it is best to study the chart which shows shaft rotation to determine the required model.

HYDRAULIC PUMP INDEXING

The transmission front output and pump housing are designed to permit the pump to be mounted in either of two positions. Each position permits oil to be pumped when pumps are counter-rotative one direction only. The pump can only pump oil when any point on the gear is crossed just the first, just first, then just the second raised portion of the pump housing which separates the inlet from the outlet and then just the pump outlet.

The pump must be correctly indexed for each direction of rotation. An arrow with TOP L.H. and a second arrow with TOP R.H. are on each pump housing. The arrow which is located near the top of pump housing points in the direction the pump must rotate to pump oil. The arrows L.H. and R.H. describe the required pump rotation when facing the pump and calls the area rising at the arrow points out. The letters L.H. and R.H. have been removed from current pump assemblies.

The site mechanic will always check the pump setting prior to transmission installation to be sure that the arrow agrees with engine rotation.

Pump rotation is checked from the opposite end of the transmission from where shaft and engine rotation is described. The arrow showing left hand rotation should be near the top of the units used behind clockwise rotating engines. The arrow showing right hand rotation should be near the top on units used behind counterclockwise rotating engines.

2.0 INDEX PUMP FOR OPPOSITE HAND ROTATION

CAUTION: This procedure is not applicable to CR2 units or the 4WS, 4SP16, 10-17 and 10-18 models (2.10) in case substitution occurs because special planetary gear mountings are used which are different for each rotation. These models must not be substituted from the original factory settings.

1) Remove the four bolts which hold the pump to the transmission, (Fig. 1).

2) Loosen the pump housing. A rubber or plastic hammer may be used to tap the oil line, but do not collide the bolt heads.

3) Do not remove the pump from the shaft unless a seal protector is used to prevent the shaft splines from cutting the pump set.

4) Care should be taken to see that the pump gasket does not slide to the pump housing during rotation, causing the gasket to be folded or torn.

5) Locate pump with the arrow indicating the proper direction of input shaft rotation near top of transmission.

6) Care must be taken to see that the gasket, seal and shaft brace are kept in good condition to prevent leaks in these critical areas.

7) Torque the four bolts to 17-20 ft. lbs. (23-27.7 kgm.).



FIG. 1 HUB FEATHER PUMP AND DRIVE SHAFT

PROPELLER ROTATION

A right-hand propeller is a propeller which will thrust forward when turned clockwise when viewed from behind the boat looking forward.

A left-hand propeller is a propeller which will thrust forward when turned counter-clockwise as viewed from behind the boat looking forward.

CAUTION: Early gear failure will occur when the transmission must be operated in reverse/neutral forward when operated with a propeller having the wrong hand of rotation.

The required propeller is designated in the various charts as left-hand (L.H.) or right-hand (R.H.) for each transmission assembly.

TRANSMISSION RATIO SELECTION

Propeller shaft speed is determined by engine speed and transmission ratio. Drive boat has a fixed decrease shaft

speed, which has a direct relationship to boat speed. A small propeller must be used when shaft speeds are too high and this results in poor performance. A large propeller turning at high speed would overload the engine. Fast revolutions do best with direct drive units. Cruisers require reduction gears. The heavier and slower boats require correspondingly greater ratios of reduction. One hundred revolutions per minute of the propeller shaft for each mile per hour of boat speed is considered a very good rule of thumb for selecting the drive ratio.

(EXAMPLE)

A boat which runs 30 MPH has an engine which runs 3000 RPM. $3000 \div 100 \text{ RPM}$ propeller shaft optimum shaft speed, or 30 = 100/3000 RPM would be optimum shaft speed.

$$3000 = \text{Engine Speed} \div \frac{1}{\text{Reduction Required}}$$

$$3000 = \text{Shaft Speed} \quad 1$$


PROPELLER SELECTION

The propeller is selected to load the engine and still permit full power to be developed. The propeller must allow the engine to come up to total speed. It is important to use a propeller so large that the engine will be overloaded, because this will not only reduce the power delivered to the propeller shaft, but more importantly it will cause ab-

normally high loading within the engine. This can result in excessive pressures and temperatures which cause premature bearing and valve failure.

For all loading it is best to select a propeller which will permit the engine to maintain rated RPM when under load.

Figure 2 Installation drawing for in-line compressors (H 107.00 with H6000)



General Performance Data

Model	Minimum IQR and Range (1)		Minimum Pressure	Max. Rotation	Sweeping Oil Weight	
	Max. Oil Rate (kg/h)	Min. Oil Rate (kg/h)			Max. Oil (kg)	Min. Oil (kg)
H 107 H 173	100 to 3000 kg/h	50 to 2000 kg/h	1.2 bar 1.0 bar 0.8 bar	2000 rpm 2000 rpm 1500 rpm (max. 1.5 bar)	300 kg (300 kg)	200 kg (200 kg)
H 207 H 273	100 to 3000 kg/h	50 to 2000 kg/h or 200 to 2000	1.2 bar 1.0 bar 0.8 bar (max. 1.5 bar)	2000 rpm 2000 rpm 1500 rpm (max. 1.5 bar)	300 kg (300 kg)	200 kg (200 kg)
H 307 H 373	100 to 3000 kg/h	50 to 2000 kg/h	1.2 bar 1.0 bar 0.8 bar (max. 1.5 bar)	2000 rpm 2000 rpm 1500 rpm (max. 1.5 bar)	300 kg (300 kg)	200 kg (200 kg)

Dimensions (unit: millimetre)

(1) Always in operating range

Model	A	B	D ²	H _{max}	F _{max}	F _{min}
H 107 H 173	420 (420/430)	280 (280/285)	120 (120/125)	365 (365/370)	425 (425/430)	425 (425/430)
H 207 H 273	420 (420/430)	320 (320/325)	120 (120/125)	365 (365/370)	425 (425/430)	425 (425/430)
H 307 H 373	420 (420/430)	360 (360/365)	120 (120/125)	365 (365/370)	425 (425/430)	425 (425/430)

Notes:

(1) The minimum temperature during the operation is approximately 10°C and the maximum temperature should not be exceeded only in a limited and specific situation. For additional operation information, contact us. Please refer to our website.


H 107/H 173 alternative dimensions:

H 107	420
H 173	425
H 207	430
H 273	435
H 307	440
H 373	445

All values given in mm. Do not take in 2025 mm mounting

WARNING: Always correct engine oil, replace pressure plates and replace oil pump components and wear or change in the seal according to seal wear instructions. Please refer to the manufacturer's user manual for details of this type.

FIG. 2 DIMENSIONS REQUIRED FOR DRIVE TRANSMISSIONS




MODEL	A	B	C	D	E	F	REDUCTION
TC 3000	8.50 (+0.10)	1.00 (0.00)	16.50 (0.00)	12.00 (0.00)	1.00 (0.00)	10.00 (0.00)	10.0 : 1.00 : 1 1.00 : 1.00 : 1
TC 500						10.00 (0.00)	10.0 : 1.00 : 1
TC 3000	8.50 (+0.10)	1.00 (0.00)	16.50 (0.00)	12.00 (0.00)	1.00 (0.00)	10.00 (0.00)	10.0 : 1.00 : 1 1.00 : 1.00 : 1
TC 500						10.00 (0.00)	10.0 : 1.00 : 1

GENERAL SPECIFICATIONS

MODEL	MAXIMUM SIZE OF INPUT		AVAILABLE RATIOS	OUTLET ROTATION	DRY WEIGHT
	BLANKET	HEEL			
TC 500	160 x 100 mm	160 x 100 mm	10.0 : 1.00 : 1, 1.00 : 1.00 : 1	OPTIONAL	100 kg (220 lbs)
TC 3000	200 x 100 mm	160 x 100 mm 160 x 100 mm	10.0 : 1.00 : 1, 1.00 : 1.00 : 1		100 kg (220 lbs)

NOTE: All specifications and dimensions shall be verified and agreed to through written replies. Specific maintenance instructions related to model shall be indicated on request.

FIG. 100. CONTROLLER SHIMMING FOR 4 DRIVE TRANSMISSIONS



MODEL	4	4	4	4	4	4	REMARKS
TYPE 100	5000	5100	5100	5100	5100	5100	20.0, 20.0, 20.0, 20.0
	10000	10000	10000	10000	10000	10000	20.0, 20.0, 20.0, 20.0
TYPE 100	5000	5100	5100	5100	5100	5100	20.0, 20.0, 20.0, 20.0
	10000	10000	10000	10000	10000	10000	20.0, 20.0, 20.0, 20.0

GENERAL SPECIFICATIONS

MODEL	MAXIMUM SHIM INPUT		MATERIAL	EQUIPMENT	BODY WEIGHT
	GASOLINE	DIESEL			
100	200-4000 rpm	100-4000 rpm	200-400, 200, 200, 200	OPTIONAL	1000, 1000 g
100	200-4000 rpm	100-4000 rpm	200-400, 200, 200, 200	OPTIONAL	1000, 1000 g

NOTE: DIMENSIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. SPECIFY DIMENSIONS IN MILLIMETERS UNLESS OTHERWISE SPECIFIED.

YOUTH ASSEMBLY


SEX	AGE	SCHOOL / CLUB	ADDRESS / PHONE	MONEY FOR SERVICE		MONEY		TOTAL	TOTAL PER CENT
				LAST YEAR		THIS YEAR			
				AMOUNT	PERCENT	AMOUNT	PERCENT		
B	12-14	BOYS	W. J. Smith	1.00	100	1.00	100	2.00	100
			J. H. Brown	1.00	100	1.00	100	2.00	100
			T. M. Green	1.00	100	1.00	100	2.00	100
		GIRLS	M. L. White	1.00	100	1.00	100	2.00	100
			R. S. Black	1.00	100	1.00	100	2.00	100
			D. K. Gray	1.00	100	1.00	100	2.00	100
		BOYS	C. A. Jones	1.00	100	1.00	100	2.00	100
			F. D. King	1.00	100	1.00	100	2.00	100
			H. G. Lee	1.00	100	1.00	100	2.00	100
			I. J. Martin	1.00	100	1.00	100	2.00	100
			K. L. Nelson	1.00	100	1.00	100	2.00	100
			L. M. Owen	1.00	100	1.00	100	2.00	100
	GIRLS	N. P. Quinn	1.00	100	1.00	100	2.00	100	
		O. R. Scott	1.00	100	1.00	100	2.00	100	
		P. S. Taylor	1.00	100	1.00	100	2.00	100	
		Q. T. Vance	1.00	100	1.00	100	2.00	100	
		R. U. Ward	1.00	100	1.00	100	2.00	100	
		S. V. Wright	1.00	100	1.00	100	2.00	100	
	15-17	BOYS	T. W. Adams	1.00	100	1.00	100	2.00	100
			U. X. Baker	1.00	100	1.00	100	2.00	100
			V. Y. Carter	1.00	100	1.00	100	2.00	100
			W. Z. Davis	1.00	100	1.00	100	2.00	100
			X. A. Evans	1.00	100	1.00	100	2.00	100
			Y. B. Fisher	1.00	100	1.00	100	2.00	100
GIRLS		Z. C. Gibson	1.00	100	1.00	100	2.00	100	
		A. D. Hall	1.00	100	1.00	100	2.00	100	
		B. E. Ingram	1.00	100	1.00	100	2.00	100	
		C. F. Jackson	1.00	100	1.00	100	2.00	100	
		D. G. Kelly	1.00	100	1.00	100	2.00	100	
		E. H. Lewis	1.00	100	1.00	100	2.00	100	

1 - 20 members

2 - 10 members or less

3 - Includes all money received except for the 10th assembly in the year for the 10th anniversary celebration. In the year for the 10th anniversary celebration, the money for the 10th anniversary celebration is included in the 10th anniversary celebration.

FIG. 4 REDUCTION GEARBOX FOR 200-2000PSI TRANSDUCER



NOTE: PARTS ARE AVAILABLE SEPARATELY.

MODEL	J.	K.	L.	M.	N (PSI)	O (PSI)	P (PSI)	REDUCTION	INPUT/OUTPUT	
									PSI (IN)	PSI (OUT)
200-2000	1.00	1.00	10.00	10.00	100.00	100.00	100.00	100	1.00	100
								1000	100.00	1000
								10000	1000.00	10000
								100000	10000.00	100000
200-20000	1.00	1.00	10.00	10.00	100.00	100.00	100.00	100	1.00	1000
								1000	100.00	10000
								10000	1000.00	100000
								100000	10000.00	1000000

GENERAL SPECIFICATIONS

MODEL	MAXIMUM LINEAR INPUT		NONLINEAR INPUT	OUTPUT REDUCTION	DEF. TOLERANCE
	CONV. PT.	CRACK			
200-2000	1000 PSI (7.6 MPa)	1000 PSI (7.6 MPa)	1000 PSI (7.6 MPa)	OPTIONAL	±0.001 (25.4 μm)
200-20000	10000 PSI (76 MPa)	10000 PSI (76 MPa)	10000 PSI (76 MPa)	OPTIONAL	±0.001 (25.4 μm)

NOTE: The above dimensional ratings are subject to manufacturing tolerances and are intended only as general guide. Specific applications should be referred to Division Three for engineering assistance.

ADAPTER HOUSING

Adapter housings for mounting the transmission to the engine are specially manufactured for the engine make. Suction or intake engine converters. The rear face of the adapter and the adapter rear face should have a hole and corresponding slot for the 10MM x 40 hex-socket head bolt to run out. All Volvo drive transmissions which permanently maintain rear to rear drive are semi-direct shafting.

Mount. Use after installation and have installed the following adapters:

193 P, for flywheel mounting to Volvo P and V engines which have 200, 240, 245, 260, and 265 cubic inch displacements.

TRANSMISSION INSTALLATION

INSTALLING TRANSMISSION TO ENGINE

The transmission may be installed to allow the flywheel to straddle gear end of the engine. A suitable shaper assembly should be ordered and installed to either the flywheel or to an adapter, which is attached to shaper gear end of the crankshaft.

A transmission adapter should be purchased or manufactured to allow the transmission to fit the engine. The adapter or spacer must be ordered to cover the drive shaft splining mate full engagement with the drive shaft hub. Check for interference between the various parts as they are assembled.

Shaper and transmission adapter aligned should be held in 100 inch total indicator reading for both fore and aft settings.

Label the input shaft and adjust that splines to the transmission. It is essential to the engine.

The shaft should be secured into splines receiving left side to insure transmission alignment and to insure transmission weight to insure that shaper will not be displaced as transmission is installed to engine.

INSTALLATION ANGLES

The transmission and engine should be installed so that the maximum angle relative to horizontal drive transmitted 10° when the load is at rest, and should not exceed 30° when operating at the normal low high condition. A higher angle of installation along with low oil level can prevent pump circulation when operating in tough water when pitching and rolling tends to throw the oil away from the pump inlet.

193 T for flywheel mounting to Volvo P and V engines which have 200 and 220 cubic inch displacements direct engine.

193 T for flywheel mounting to Volvo P, E and V engines which are 200, 240 and 260 cubic inch displacements from the front. E and V, auxiliary engines of 200 and 220 cubic inch displacements.

TRANSMISSION FLUID

Type A, General[®] and other hydraulic fluids which meet the Detroit Diesel Allison Division or General Motors Division specifications for type CD oils are recommended for use in all Volvo drive marine gears.

Labeling grade oils are recommended for use in Volvo engines and GM within Allison specifications for EE oils may be used in other drive marine gears if the engine RPM does not exceed 3000 RPM. If GM is preferred, GM 100 is acceptable if high operating temperatures are anticipated. When choosing oils such as 10W-60 are not acceptable. The foundation is 100-WP marine grade "CD" oils. The second choice is 100-WP marine grade "CC" oils.

The equivalent 100W oil grades are:

- 100 MIL-L-15550
- 100 MIL-L-15550

These three drive classes of General Motors developed the EE specifications for oils to used in their hydraulic systems and gear differentials systems. These oils are certified for use in all Volvo Drive marine gears.

Each oil company will provide information and specifications on their products which fit in the above specifications.

NOTE: Be sure the seals properly installed and the transmission lubricated before making or during the engine.

CHECKING OIL LEVEL

The oil level should be maintained at the full mark on the dipstick. Check oil level after no starting the engine.




FIG. 2. FIGURE THREE (LEFT AND MIDDLE)




FIG. 3. FIGURE FOUR (MIDDLE AND RIGHT)

FILLING AND CHECKING THE HYDRAULIC SYSTEM

Check oil levels before starting engine. The Volvo Drive Hydraulic system includes the transmission, oil cooler, power line assembly, pump and associated lines and hoses.

The complete hydraulic circuit must be filled after filling the transmission and the engine pump. The system of oil cooler hoses and hoses should be checked. The hydraulic pump hoses by connecting all hoses must be checked. The correct system working while the engine is running at approximately 1500 RPM. The pressure of oil is between the hydraulic circuits that the system has constant pressure of 20.

TRANSMISSION OPERATION

STARTING ENGINE

Place transmission selector lever in neutral before starting engine. Shifts from any selector position to any other selector position may be made at any time and in any order if the engine speed is below 1500 RPM. However, it is recommended unless an shift is made in the neutral position.

NEUTRAL

Place the shift lever to the center position where the spring loaded ball enters the detent hole in the side of the shift lever and properly locate lever in neutral position. Shift lever ball is positioned. Now it is not to double is located in the neutral position. The ball enters the hole in a position of the side and complete interruption of power transmission is done.

FORWARD

Place the shift lever to the forward/forward position where the spring loaded ball enters the detent hole in the side of the shift lever and properly locate lever in forward position.

REVERSE

Place transmission shift lever to the reverse/reverse position where the spring loaded ball enters the detent hole in the side of the shift lever and properly located it in the reverse position.

See specifications in a product literature should be checked to ensure that the oil level on drain back into the transmission from the cooler and connections. Check the oil level in this area has about once, immediately after the engine is shut off and again after the engine has been stopped for more than one hour. Overweight is possible.

It is indicated increase in the oil level after the waiting period indicates that the oil is seeping from cooler and cooler lines. The external plumbing should be checked to ensure any leak back.

FORWARD

Place selector lever in the forward position. The design of the Volvo Drive gear requires adequate cooling and lubrication.

REVERSE

The detent balls of the hydraulic system, a pressure pump should be located in the hydraulic line. The pump system should be correct overall composition is 1500 to 1600, 1600-1700, pressure composition is constant 0.75 kg/cm².

PROPELLER SHAFT COUPLINGS

KEYING TO SHAFT ALIGNMENT

Section 1008 describes the construction of coupling installation from Marine Star.

The propeller shaft coupling must be aligned to the propeller shaft. The key should be a straight cut key and will require either flat shims between the securing flanges or shimming the hub. The coupling alignment is determined from the shaft and key. It should be flat across parallel to the shaft.

NOTE: Propeller shaft coupling alignment may occur when the propeller shaft is in a low compression under the air required for the particular coupling. This alignment may occur in a low compression under the air required for the particular coupling. This alignment may occur in a low compression under the air required for the particular coupling. This alignment may occur in a low compression under the air required for the particular coupling.

Two common methods for fitting the coupling to the propeller shaft are used. Type 1 couplings are fitted where the shaft has setscrews and the shaft and components of the coupling must be drilled with the coupling in position on the propeller shaft. It is not difficult to determine alignment but care is taken in the coupling and shaft to make these parts. The propeller shaft should be checked to see if it will be the same length as the coupling hub (the shaft end should be approximately 1/16" from the coupling when assembled).

Type 2 couplings are fitted and tapped for all sizes which are used for main drive gears. Some propeller shaft couplings are drilled and tapped for all sizes, and are also drilled for set screw installation.

ALIGNMENT COUPLING TO PROPELLER SHAFT COUPLING ALIGNMENT

Whether you use one of the two methods of alignment and fitting flanges can be used for alignment of the propeller shaft coupling and propeller shaft coupling. The propeller shaft is usually fixed to the hull structure and alignment is achieved by adjusting the propeller shaft coupling to the propeller shaft.

Proper alignment of the coupling flange should be achieved by using the following methods and procedures. The propeller shaft is usually fixed to the hull structure and alignment is achieved by adjusting the propeller shaft coupling to the propeller shaft. The propeller shaft is usually fixed to the hull structure and alignment is achieved by adjusting the propeller shaft coupling to the propeller shaft.

The propeller shaft is usually fixed to the hull structure and alignment is achieved by using the following methods and procedures. The propeller shaft is usually fixed to the hull structure and alignment is achieved by using the following methods and procedures.

Check coupling alignment with atmospheric level from the coupling. Check that coupling is parallel with the shaft to the coupling. Check that coupling is parallel with the shaft to the coupling. Check that coupling is parallel with the shaft to the coupling. Check that coupling is parallel with the shaft to the coupling.

Adjustment is necessary when shaft and coupling are in the same line of center and the following New Standard Alignment Methods are used.

NOTE: Do not use a key which is too small. The coupling should be checked to see if it will be the same length as the coupling hub (the shaft end should be approximately 1/16" from the coupling when assembled).

USE OF FLEXIBLE COUPLINGS

Flexible couplings are used to reduce noise and vibration. Flexible couplings are used to reduce noise and vibration. Flexible couplings are used to reduce noise and vibration. Flexible couplings are used to reduce noise and vibration.



FIG. 1. PROPELLER SHAFT COUPLING

The adjustment of the propeller shaft to the transmission output shaft should always be maintained even when the shaft couplings are used.

Correct mounting is essential for the shaft when there are no couplings or dry joints.

DRIFT LEVER

The oil flow in the hydraulic circuit is controlled by a control valve which is operated by the drift lever. To make the double function possible, the drift lever must be in the correct position, defined by the dimensioned coil spring located between the coil and the lever, so that proper force and positioning can be obtained at the transmission when the control lever is pulled in the test operator's action.

The accuracy is guaranteed if the drift lever control spring profile height is permanently measured, or if the control lever is changed in its position, or repositioned, or if the change between the control system and the transmission is not the same in both installation directions.

SCREWING QUALITY

Manufacturers refer to screw threads, diameters, etc. and stress levels at general points.

Mounting and retreating bolts and brackets can reduce the thread engagement. These bolt length and quality are required.

When brackets are fitted to the output shaft bearing or other and adjustment, all fasteners to be used in the area.

Subsidiary of the transmission due to loss of all other external elements but essential to the system.

WARNING

The test lever transmission should be pulled to prevent screw twisting. The other end bearing procedure will be similar to that used on the engine.

Care must be taken to keep joints away from areas which are prohibited. Dimensions or dimensions, tolerances or gaps should be checked on these parts to ensure gaps from twisting. This may be done from the following parts:

1) The joint diameter of the mounting base that must not experience twisting.

2) The thrust shaft spline which mates with the thrust thrust hub.

3) The output shaft coupling flange which mates with the propeller shaft coupling hub.

4) The shaft end sleeve and coil spring. An accumulation of wear from all causes proper action of the sleeve.

5) The screw plate should not be painted, otherwise the screw and nut's function may be impaired. A coat and maintenance should be available for ordinary parts.

COOLERS

TRANSMISSION COOLING REQUIREMENTS

WARNING: Transmission temperature is critical. Excessive cooler air flow can cause damage to the cooler itself.

The pressure regulator system controls transmission flow to achieve a certain amount of oil. Air-side temperature will become excessively high when a cooler is not connected to the cooler circuit. The transmission may be operated with a cooler bypass valve connected to the cooler circuit when an emergency valve and the transmission may be operated in other than idle conditions. However, maintaining a hot engine.

Better efficiency and extended gear life will result when the transmission sump temperature is maintained between 160°F and 180°F with Cooler 200. Transmission pressures are dependent upon cooler flow. It is imperative when a cooler which has variable flow characteristics as well as proper cooling capacity. Excess back pressure affects fuel and cooler pressure flow characteristics. An extended period of low cooling efficiency will lead to excessive wear. The low back pressure.

COOLER LEAKS

Hydraulic flow with a minimum of 1000 in/min (100000 in/min) under normal, standard size or flow things, should be used. Always check for leaks through the pump, ensuring the oil flow. Excess tubing should be avoided due to its tendency to break things and become weak when subjected to vibration.

WATER-GLASS COOLERS

The cooler built and sold by Water Glass has been designed. These coolers come of the single pass type and come approximately 1/2 inches (1.25 cm) in diameter. The 1/2, 1, 2 & 4 in the chart refers to the length in inches of the main body of these coolers. This information should be helpful in determining the size of cooler to select for use with the listed flow capacities.

COOLER SIZE

The cooler size must be related to the cooler circuit and flow rate of engine and transmission. The amount of cooling required depends upon engine and transmission power, ambient air temperature and wind direction and speed.

RECOMMENDED FLOW FOR COOLERS INCLUDING

COOLER SIZE (IN)	FLOW (GPM)	TRANSMISSION	TRANSMISSION TYPE
1/2	100	750	DRIFT ENGINE
1	100	750	DRIFT ENGINE
1	100	750	ALL REDUCING RATIO
1	100	750	ALL REDUCING RATIO 1/2 (2000 RPM)
1	100	750	DRIFT ENGINE
1	100	750	ALL REDUCING RATIO
1	100	750	ALL REDUCING RATIO
1	100	750	ALL REDUCING RATIO
1	100	750	ALL REDUCING RATIO
1	100	750	ALL REDUCING RATIO
1	100	750	ALL REDUCING RATIO

The recommendations given above are based on typical engine engine conditions which have a maximum water temperature at the cooler inlet of 180°F or 80°C and a maximum water flow of 50 GPM (gallons per minute) or 1.8 m³/min. A large amount of water will be required when water temperature rises to a temperature between 180°F or 80°C.

Coolers are available from many sources. Each cooler design has its own characteristics of cooling capacity and of flow restriction. When these characteristics affect heat transfer performance, the cooling system should be tested after installation to determine that temperature and pressure fall within recommended limits.

WATER-FLOW RATE

Water flow rates of from 50 to 200 GPM (1.8 to 7.6 m³/min) are available for cooling air/Water Drive Systems.

WATER TEMPERATURE PROBLEMS

Flow water should be fed directly to cooler, otherwise the 180°F (80°C) maximum water inlet temperature may be exceeded. Water temperature above 180°F (80°C) is permissible only if large steel coolers are used to maintain recommended transmission temperature.

CONNECTING COOLER TO TRANSMISSION

WARNING: You must always determine the transmission to cooler and cooler return location for each transmission. Refer to the following information for the location of the transmission and cooler return lines. Always use the correct hose and fittings to make the proper connection. It is very important to use the correct hose and fittings. Cooler return and to cooler hoses are to be used on the various transmission drawings which may be found in this manual and also in the various service manuals. Be aware of hose changes or differences which occur on new production and revisions.

NOTE: Transmissions are currently being shipped with plastic plug installed in the cooler and cooler return openings to identify their location.



12-LINE INDUCTION TRANSMISSION

FIG. 10



12-LINE INDUCTION TRANSMISSION

FIG. 11



4-SPEED 2-GEAR REDUCTION GEAR TRANSMISSION

FIG. 12



4-SPEED 2-GEAR REDUCTION GEAR TRANSMISSION

FIG. 13

LOCATION OF MANUAL TRANSMISSION (OPTIONAL) AND RANGE SELECTOR

- | | |
|-------------------|--------------------|
| 1. RANGE SELECTOR | 7. RANGE SELECTOR |
| 2. RANGE SELECTOR | 8. RANGE SELECTOR |
| 3. RANGE SELECTOR | 9. RANGE SELECTOR |
| 4. RANGE SELECTOR | 10. RANGE SELECTOR |
| 5. RANGE SELECTOR | 11. RANGE SELECTOR |
| 6. RANGE SELECTOR | 12. RANGE SELECTOR |

COOLER UNIT LOCATION

Mount cool to the oil leaving the transmission.

The cooler unit location for all 700, F10 and F10-100 is 1.500 transmission is located just behind the oil filter inlet at the top rear of the forward and reverse transmission case.

The cooler unit location for all 700 series transmissions is 1.500 transmission case.

The cooler unit location for 700 series units is located just behind the oil filter inlet at the top rear of the forward and reverse transmission case.

The cooler unit location for the Gear-Center units is located just behind the oil filter inlet at the top rear of the forward and reverse transmission case.

COOLER UNIT OIL CONNECTION

Connect cool to the oil entering the transmission.

The cooler unit location for all direct drive units of the 700, F10, F10-100 and 700-100 series transmissions is the circulating oil pump in the transmission case.

Early reduction units of the 700, F10, F10-100 and 700-100 1.500 transmission is located inside the transmission case rear side of the reduction housing (Figure 6). All units having the reduction housing offset and located at the lower right side must have cooler oil returned to the frame.

Reduction units of the 700, F10, F10-100 and 700-100 series which incorporate the helical housing opposite oil location, must locate cooler oil return to the same fitting on the lower right side of the forward and reverse transmission case.

The 1.500 reduction transmission of the 700, F10, F10-100 and 700-100 1.500 series are helical housing offset and require cooler oil return at the rear of the reduction housing (Figure 6). Any 1.500 reduction housing which is offset and support for 1.500 series fitting on the cooler must have cooler oil returned to the case.

All cooler 700 transmissions are currently manufactured to have cooler oil returned to either end of the case location at the right rear front end of the forward and reverse transmission case (Figure 6). The other case return fitting should be plugged.

Units with two cooler oil returns to an springplate is located at the lower rear of the F10-100 case.

Gear-Center reduction units have cooler oil returned to the same fitting on the lower right side of the forward and reverse transmission case.

Best cooling efficiency will be obtained when oil and cooling water flow in opposite directions. A large flow cooler may be required when oil and water flow in the same direction through the cooler.

HOUSING COOLER

Oil can be cooled above the oil to a cooler when the cooler unit fitting is located at the highest point in the case. Temperature reduction capability, cooler fitting pipe location, use of air through the cooler, and intake oil level influence.

Helical housing is preferred because it prevents oil from draining from the cooler. Drain back from axles which is returned higher than the transmission case will give a cooling high cooling efficiency at least three times. It is best to mount the cooler at some level to give below transmission centerline.

FIG. 6 COOLER MOUNTING AND CONNECTION



All cooler units are connected to an angle should have cooler flow direction for oil to flow into the case at fitting end and of the higher oil fitting.

FIG. 7 COOLER MOUNTING ON HELICAL HOUSING



Circle problems may be the result of failure to design bearing accommodations in proper planning practice. If a failure or loss of bearing occurs because of the manufacturing bearing dimensional variations, it is to be proven existing the oil film. Therefore should not be the start or end of a differential dimensional quality from such cases. Secure all fits to prevent

drifting and chafing. Many faults should be avoided to make possible free dimensional variations can be caused by such practice.

It is possible for some fits to occur inside clearance, resulting in fit flow into the case or case-flow into shaft.

VIBRATION DAMPERS

DEFINITION REQUIREMENTS

The subject here deals with all types of vibration dampers, designed to absorb into the hub of a vibration damper. Vibration dampers may be attached to the engine crankshaft or other the flywheel or crankshaft end.

The damper presents angles reduced or some vibrations depending upon the vibration. The most severe applications encountered by the designer include: those vibrations are caused the varying velocity of the vibration damper and result in gas action and are some resonance factors. Having the rate speed slightly out away from the vibration.

The designer will design compression ratio change vibration cases than a gasless engine, compression ratio and the number of cylinders for a given horsepower engine vibration frequency and methods.

The frequency, compression ratio, number of cylinders, displacement, engine inertia, flywheel inertia, loading speed in RPM, weight of propeller shaft, type of propeller and many other variables all have a bearing on determining the correct damper for the particular application.

Factors due to increase choice of the damper are more frequent in boats which are used for trolling and other fishing activities where the compression ratio varies from 11 to over 16:1 RPM. Many types of propeller failures, such as crankshaft teeth, broken shafts and clutch slams are the result of improper choice of damper.

DESIGN

Each engine has its own characteristics of vibration and inertia. The application engineer must select the correct damper most suitable for the particular make of engine,

type damper, due to the particular demands of that engine, may be suitable for one engine make only. Refer to damper manufacturer's P.I.

Notes: One does not assume the responsibility for recommending the proper engine flywheel and damper size for the installation of our transmission. Hence, user will supply all systems and information which is available to permit a transmission system analysis.

The following procedure is recommended for selecting a suitable engine flywheel and damper size when a suitable damper is not available.

1. If possible, select a flywheel with a constant of inertia as nearly equal to one which is being considered, and in other respects an inherent application of the engine. If this is impossible, select a flywheel with a slightly greater constant of inertia. Never select a flywheel with an inertia if it can be avoided in the light of all available information for RPM control systems.

2. Check information concerning the damper design type and then operating ratio, as presented in the table just now used with the above flywheel, so that better than one, depending if it has available a damper size which has similar characteristics.

3. If a damper size cannot be furnished by the user (due to its production quantity, space and information limitations), and installation will have to be substituted, a constant damper size usually. This will allow the determination of a proper damper by experimenting with various springs.

ENGINE APPLICATIONS CHART

AND

ENGINE ASSEMBLY WHICH ARE CURRENTLY AVAILABLE FROM HUBBARD CRANE

The following chart gives suggested maximum engine and engine alternator for the which these starters are designed. Due to wide variations between individual battery ratings, all applications must be tested by the user to insure satisfactory operation.

STARTER	RECOMMENDED BATTERY*	VOLTAGE RATED	MAXIMUM ENGINE* HUBBARD CRANE TORQUES							
			DIESEL ENGINES				GASOLINE ENGINES			
			4 CYL.	6 CYL.	8 CYL.	10 CYL.	4 CYL.	6 CYL.	8 CYL.	10 CYL.
12 VOLT	W300-1200 (B)	120	100	100	75	50	70	50	50	50
	W300-1200 (C)	200	150	150	100	50	150	50	50	50
	W300-1200 (D)	300	200	200	200	150	250	100	100	100
	W300-1200 (E)	350	200	200	200	200	200	200	200	150
	W300-1200 (F)	400	400	375	325	275	300	300	300	200
	W300-1200 (G)	400	400	375	325	275	300	300	300	200
24 VOLT	W300-2400 (B)	120	100	100	75	50	70	50	50	50
	W300-2400 (C)	200	150	150	100	50	150	50	50	50
	W300-2400 (D)	300	200	200	200	150	250	100	100	100
	W300-2400 (E)	350	200	200	200	200	200	200	200	150
	W300-2400 (F)	400	400	375	325	275	300	300	300	200
	W300-2400 (G)	400	400	375	325	275	300	300	300	200
	W300-2400 (H)	500	500	400	350	300	300	300	300	200
	W300-2400 (I)	500	500	400	350	300	300	300	300	200
	W300-2400 (J)	500	500	400	350	300	300	300	300	200
	W300-2400 (K)	500	500	400	350	300	300	300	300	200
36 VOLT	W300-3600 (B)	100	100	100	100	100	100	100	100	
	W300-3600 (C)	100	100	100	100	100	100	100	100	

- (B) 120 volt starters are usually installed in the timing gear end of the engine.
- (C) 150 volt starters are usually installed in the flywheel end of the engine.
- (D) 200 lb. size of the bolt circle for Borg & Beck and Long shaft crane start fixtures.
- (E) 300 lb. size of the bolt circle for Borg & Beck and Long shaft crane fixtures, which are under 12" in diameter.
- (F) Size is 10000 inch bolt circle with six 1/2" diameter bolt holes in a 17 1/2 inch diameter mounting plate.
- (G) Fits same brackets for larger Bradford, Long and Borg & Beck starters for diesel engines.
- (H) These assemblies have full capacity in both directions.
- (I) These assemblies are for L, R engines however, may be used for R-L engines when tested 50-60%.
- (J) Fits size with same 10000 mounting plate only.

DAMPER INSTALLATION

INSTALLATION DRAWINGS

Damper installation drawings are available from Service Data Division. Be advised that both engine data concerning ball joint locations and other data which may be required for making an installation, may have to be obtained.

SPRING ENGAGEMENT

The engine manufacturer should be notified concerning damper design to be sure that the damper is designed and constructed for engagement into the damper hub splines. There should not be adequate clearance between the damper and transmission case. (Preparations have been undertaken for transmission modifications to allow greater clearance.) Before the engine starts, be certain that the splines are fully engaged. The spring of the input shaft should be removed and to heavy one splined damper hub.

DAMPER END, 75

Body fit bolts used to hold the damper to the engine should be spaced. Torques should be in "low" and heavy section bolts.

DAMPER END

Damper drive for timing gear and installation require a flange hub to connect the crank shaft with the damper assembly.

EARLY DAMPER SPLINE

The early 1964 Ford three transmission input shaft has 10 splines, instead of the 30 splines which are currently being supplied. Early damper assemblies were supplied with ten splines to mate with the early transmission input shaft splines. These ten spline damper assemblies may still be produced for existing only installations. However, these assemblies may be discontinued in field requirements drawings.

DAMPER PROBLEMS

An unusually high engine rpm cause the damper to vibrate. This noise usually will go away as the engine speed is reduced about 1000 to 1500 RPM. The cause is usually the spring in the damper loosening and or going wild.

A damper which is not correct for the particular engine will cause even though the engine runs properly.

A splin will sometimes shatter after a transmission overhaul. This splin is usually caused by a distorted damper. The damper may be distorted during transmission removal or assembly when the transmission input shaft splines are not engaged with those of the transmission. Submitted to this effect, this showing a bending ball joint damper hub.

Transmission gears will sometimes rattle when a damper problem exists. Test rattle is usually the result of an improper adjustment, and does normally indicate faulty transmission gears.

A new model switch kit (part number 7000-00000) is now available and will replace the earlier kit (number 71-0000).

Kit 70-04 000-000 contains the following parts:

1	7000-00000	Switch and body assembly
1	7000-00000	Switch and "O" ring assembly
1	7000-00000	Switch
1	7000-00000	"O" Ring
1	70-00000	Wash cover
1	70-00000-001	Switch cap
1	70-000	Transmission mounting
1	70-000	Oil level indicator
1	70-00	Wash cover
1	70-00	Wash cover gasket
1	70-000	Instruction sheet

The new switch and wash cover have a 100-00000-04 thread. An "O" ring is used to seal between indicator and switch. This kit is supplied as shown above these quantities. The complete kit is required for converting the earlier kit 71-0000.

TRANSMISSION ALARM KIT 7000-000

This is the recommended method for monitoring transmission functions. This temperature will rise to indicate low oil level, low pressure or mechanical problems earlier than a pressure gauge will indicate a drop in pressure.

TRANSMISSION ALARM KIT 7000-000-001

This kit is used in conjunction with the 7000-000-001. This kit provides auto-temperature for making a dual oil-level indicator.



FIGURE 10 TYPICAL THIRD GEAR END INSTALLATION



FIGURE 11 TYPICAL FOURTH END INSTALLATION



FIGURE 12 THIRD INSTALLATION - Showing Gear End & Counter Shafting from Outside Viewpoint on Gear.



FIGURE 13 SINGLE GEAR INSTALLATION - Showing Right and Left Gear End Views. Right hand view only will show other than left hand problems.



FIGURE 14 First Gear Section of Gear Shaft. Showing Gear End View with Drive Shaft. Particular to the gear end view. Looking into gear the other gear end view of the gear end. Gear end view will show other than left hand problems.