

Navigation: [Home](#) => [Profil](#) => SeaTalk
Stand: 29.07.2017

SeaTalk Technical Reference Revision 3.23

General Information

SeaTalk is a simple interface for networking [Raymarine/Autohelm](#) marine equipment so that all devices of a ship can exchange and share their data. SeaTalk is a proprietary solution of Autohelm and **not** compatible with NMEA or CAN. Unfortunately Raymarine keeps the technical details of SeaTalk secret. To assist users who want to develop hard- or software to connect their devices to the SeaTalk bus these pages uncover some of the mysteries. Part 3 adds hints how to interface SeaTalk with a PC. The information is unsupported by Raymarine and was found by watching the bits travelling on the bus. Therefore the description is incomplete inaccurate and may even be wrong. [Corrections and contributions](#) are welcome.

Content

The technical description of the SeaTalk protocol is divided into three parts:

1. [Part 1: How SeaTalk works](#)
 - a. [Hardware-Interface](#) describes the function of the three SeaTalk wires
 - b. [Serial Data Transmission](#) describes the parameters of the asynchron serial port
 - c. [Composition of Messages](#) describes the structure of datagrams
 - d. [Collision Management](#) describes the arbitration between simultaneous talkers
 - e. [Data Coding](#) describes common rules for coding numerical values
2. [Part 2: Recognized Datagrams](#) describes the SeaTalk messages and their meaning
3. [Part 3: Processing SeaTalk Data with a PC](#)
 - a. [Circuit example for an unidirectional SeaTalk => PC interface](#)
 - b. [Circuit example for a bidirectional SeaTalk <=> PC interface](#)
 - c. [Simple SeaTalk monitoring utility for download](#)
 - d. [SeaTrack: VisualBasic software for trip documentation](#)
 - e. [SeaSigma: A small SeaTalk command generator for download](#)

Revision History:

Rev 3.23: [July 2017] Commands 85 and 89 corrected thx Mindert Sprang and Hans Almquist
Rev 3.22: [May 2014] Command 53 corrected thx John Rind and Meindert Sprang
Rev 3.21: [March 2011] Time coding in command 54 clarified thx Tim Thornton
Rev 3.20: [January 2011] Some observations with Raystar 120 GPS included thx Tim Thornton
Rev 3.19: [August 2010] Command A2 revised thx Frank Wallenwein
Rev 3.18: [March 2009] Several commands edited and new commands 05 and 68 added thx Frank Wallenwein
Rev 3.17: [February 2009] Command A4 added thx Tord Lindner
Rev 3.16: [October 2008] Commands 65, 66, A8 and AB added thx Ray Holland
Rev 3.15: [June 2006] Command 61 added thx Ian Molesworth
Rev 3.14: [January 2006] Minor changes to commands 26, 01 and 6C thx Ian Molesworth
Rev 3.13: [December 2005] Additional bits found in command 26 by Pim Snoeks

Acknowledgement

Many thanks to

Knut Wiren, Finland

[Mikael Wahlgren](#), Sweden (developed a PIC-based SeaTalk remote control)

Reiner Patommel, Danmark

Arnold de Maa, Holland

[Wouter van Ooijen](#), Netherlands (developed a PIC-based SeaTalk protocol converter)

[Jürgen Saniter](#), Germany (developed a SX-28 based SeaTalk remote control)

Harald Sammer, Scotland

Ales Janhar, Slovenija (developed the SeaSigma utility)

[Jon Fick](#), USA (developed a PIC-based SeaTalk remote control)

[Frank Wallenwein](#), Germany ([NMEA <=> SeaTalk Bridge and several boat electronics projects](#))

Dave Martin, Great Britain

Horacio Martinez del Pezzo, Argentina (developed an intelligent SeaTalk / NMEA multiplexer)

[Pit Förster and Jochen Buttkereit](#), Germany (supplier of third party SeaTalk equipment for instance [Brookhouse interfaces](#))

[Louis Zammit Mangion](#), Malta (developed a PIC-based SeaTalk remote control)

[Meindert Sprang](#), Netherlands (develops and manufactures NMEA/SeaTalk/Bluetooth/RS232-multiplexers)

Dennis Hambleton, Australia

[Fernando MAS CADIZ](#), Spain

Ray Holland, Australia (developed a [WakeUp Marine Alarm](#) box)

Tord Lindner, Sweden and

Tim Thornton, United Kingdom ([TeamSurv](#) project for navigational data logging and [Smartcom Software Ltd.](#))

who contributed valuable information for this page.

[Return to Top of Page](#) [Part 1](#) [Part 2](#) [Part 3](#)

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part 1
Stand: 01.02.2009

SeaTalk Technical Reference Part 1: How SeaTalk works

Hardware-Interface

SeaTalk uses three wires, connected in parallel to all devices on the bus:

1. +12V Supply, red
2. GND Supply, grey
3. Data Serial Data, yellow: +12V=Idle/Mark=1, 0V=Space/Data=0, 4800 Baud, pullup circuit in each device, talker pulls down to 0V (wired OR). For [connection to a RS232 receiver](#) voltage levels must be inverted.

Serial Data Transmission

11 bits are transmitted for each character:

- 1 Start bit (0V)
- 8 Data Bits (least significant bit transmitted first)
- 1 Command bit, set on the first character of each datagram. Reflected in the parity bit of most UARTs. Not compatible with NMEA0183 but well suited for the multiprocessor communications mode of 8051-family microcontrollers (bit SM2 in SCON set).
- 1 Stop bit (+12V)

Composition of Messages

Each datagram contains between 3 and 18 characters:

1. Type of command (the only byte with the command-bit set)
2. Attribute Character, specifying the total length of the datagram in the least significant nibble:

Most significant 4 bits: 0 or part of a data value

Least significant 4 bits: Number of additional data bytes = n =>

Total length of datagram = 3 + n characters

3. First, mandatory data byte
4. - 18. optional, additional data bytes

No datagrams or devices carry addresses. This eliminates the need for an initialization or arbitration phase on the bus. Events (such as a keystroke) are published as soon as they occur. Measured data is repeatedly transferred, typically about once per second. So the current values are always available to all devices on the bus and there is no need (and with the exception of command A4 no way) to request a particular information.

Collision Management

There is no master on the bus. Every device has equal rights and is allowed to talk as soon as it recognizes the bus to be idle (+12V for at least 10/4800 seconds). Low priority messages use a longer or randomly selected idle-bus-waiting-time. This allows messages from other devices with a higher priority to be transmitted first. The different waiting times of all devices make data collisions (two or more devices start

talking at exactly the same moment) very rare. Since each device also listens to its own transmission it will recognize when its message is garbled by a second talker. In this case it abandons the remaining characters of the datagram. It waits for the bus to become free again and then retransmits the whole message. For listeners this means that messages which are shorter than expected are invalid and have to be cancelled totally.

Data Coding

Some characters are repeated with all bits inverted for noise or transmission error detection. Example: 0xA2 is followed by 0x5D. The sum of both bytes must always be 0xFF. The listing below shows repeated bytes in small letters (example: ZZ zz).

Numerical values are transmitted binary coded and with least significant data first. Example: 0x13 0x57 means $0x5713 = 22291$

Some values are put together by certain bits of a byte or nibble. The meaningful bits can be isolated by a bitwise AND operation (&). Example: (U & 0x3) filters the least significant two bits of U.

The "distance to destination" value (ZZZ in command 0x85) uses a scaling factor of 1/10 or 1/100 nm depending on the shift indicator bit (LSBit of Y).

[Return to Top of Page](#) [Overview](#) [Part 2](#) [Part 3](#)

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part2
 Stand: 29.07.2017

SeaTalk Technical Reference Part 2:

Recognized Datagrams (in hexadecimal notation):

Com Att Dat Dat...

00 02 YZ XX XX Depth below transducer: XXXX/10 feet
 Flags in Y: Y&8 = 8: Anchor Alarm is active
 Y&4 = 4: Metric display units or
 Fathom display units if followed by

command 65

Flags in Z: Z&4 = 4: Transducer defective
 Z&2 = 2: Deep Alarm is active
 Z&1 = 1: Shallow Depth Alarm is active
 Corresponding NMEA sentences: DPT, DBT

01 05 XX XX XX XX XX XX Equipment ID, sent at power on, reported examples:
 01 05 00 00 00 60 01 00 Course Computer 400G
 01 05 04 BA 20 28 01 00 ST60 Tridata
 01 05 70 99 10 28 01 00 ST60 Log
 01 05 F3 18 00 26 0F 06 ST80 Masterview
 01 05 FA 03 00 30 07 03 ST80 Maxi Display
 01 05 FF FF FF D0 00 00 Smart Controller Remote Control Handset

05 03 0X YY ZZ PP Engine RPM and PITCH:
 X = 0: RPM & PITCH
 X = 1: RPM & PITCH starboard
 X = 2: PRM & PITCH port
 YY*256+ZZ = RPM Value (signed value, example:
 YYZZ=0x0110=272 RPM, YYZZ=0xfef0= -272 RPM)
 PP = % Pitch (signed value -128%...+127%, example
 0x03=3%, 0xFD= -3%)

10 01 XX YY Apparent Wind Angle: XXYY/2 degrees right of bow
 Used for autopilots Vane Mode (WindTrim)
 Corresponding NMEA sentence: MWV

11 01 XX 0Y Apparent Wind Speed: (XX & 0x7F) + Y/10 Knots
 Units flag: XX&0x80=0 => Display value in Knots
 XX&0x80=0x80 => Display value in Meter/Second
 Corresponding NMEA sentence: MWV

20 01 XX XX Speed through water: XXXX/10 Knots
 Corresponding NMEA sentence: VHW

21 02 XX XX 0X Trip Mileage: XXXXX/100 nautical miles

22 02 XX XX 00 Total Mileage: XXXX/10 nautical miles

23 Z1 XX YY Water temperature (ST50): XX deg Celsius, YY deg Fahrenheit
 Flag Z&4: Sensor defective or not connected (Z=4)
 Corresponding NMEA sentence: MTW

24 02 00 00 XX Display units for Mileage & Speed
 XX: 00=nm/knots, 06=sm/mpg, 86=km/kmh

25 Z4 XX YY UU VV AW Total & Trip Log
 total= (XX+YY*256+Z* 4096)/ 10 [max=104857.5] nautical miles
 trip = (UU+VV*256+W*65536)/100 [max=10485.75] nautical miles

- 26 04 XX XX YY YY DE Speed through water:
 XXXX/100 Knots, sensor 1, current speed, valid if D&4=4
 YYYY/100 Knots, average speed (trip/time) if D&8=0
 or data from sensor 2 if D&8=8
 E&1=1: Average speed calculation stopped
 E&2=2: Display value in MPH
 Corresponding NMEA sentence: VHW
- 27 01 XX XX Water temperature: (XXXX-100)/10 deg Celsius
 Corresponding NMEA sentence: MTW
- 30 00 0X Set lamp Intensity; X=0: L0, X=4: L1, X=8: L2, X=C: L3
 (only sent once when setting the lamp intensity)
- 36 00 01 Cancel MOB (Man Over Board) condition
- 38 X1 YY yy Codelock data
- 50 Z2 XX YY YY LAT position: XX degrees, (YYYY & 0x7FFF)/100 minutes
 MSB of Y = YYYY & 0x8000 = South if set, North if cleared
 Z= 0xA or 0x0 (reported for Raystar 120 GPS), meaning unknown
 Stable filtered position, for raw data use command 58
 Corresponding NMEA sentences: RMC, GAA, GLL
- 51 Z2 XX YY YY LON position: XX degrees, (YYYY & 0x7FFF)/100 minutes
 MSB of Y = YYYY & 0x8000 = East if set, West if cleared
 Z= 0xA or 0x0 (reported for Raystar 120 GPS), meaning unknown
 Stable filtered position, for raw data use command 58
 Corresponding NMEA sentences: RMC, GAA, GLL
- 52 01 XX XX Speed over Ground: XXXX/10 Knots
 Corresponding NMEA sentences: RMC, VTG
- 53 U0 VW Course over Ground (COG) in degrees:
 The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 the two higher bits of U / 2 =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 8$
 The Magnetic Course may be offset by the Compass Variation (see
 datagram 99) to get the Course Over Ground (COG).
 Corresponding NMEA sentences: RMC, VTG
- 54 T1 RS HH GMT-time: HH hours,
 6 MSBits of RST = minutes = $(RS \& 0xFC) / 4$
 6 LSBits of RST = seconds = $ST \& 0x3F$
 Corresponding NMEA sentences: RMC, GAA, BWR, BWC
- 55 X1 YY yy TRACK keystroke on GPS unit
 keycodes identical with autopilot ([command 86](#))
- 56 M1 DD YY Date: YY year, M month, DD day in month
 Corresponding NMEA sentence: RMC
- 57 S0 DD Sat Info: S number of sats, DD horiz. dillution of position, if S=1
 -> DD=0x94
 Corresponding NMEA sentences: GGA, GSA
- 58 Z5 LA XX YY LO QQ RR LAT/LON
 LA Degrees LAT, LO Degrees LON
 minutes LAT = $(XX*256+YY) / 1000$
 minutes LON = $(QQ*256+RR) / 1000$
 Z&1: South (Z&1 = 0: North)
 Z&2: East (Z&2 = 0: West)
 Raw unfiltered position, for filtered data use commands 50&51
 Corresponding NMEA sentences: RMC, GAA, GLL
- 59 22 SS MM XH Set Count Down Timer
 MM=Minutes (00..3B) (00 .. 63 Min), MSB:0 Count up start flag

```

SS=Seconds ( 00..3B ) ( 00 .. 59 Sec )
H=Heures ( 0..9 ) ( 00 .. 09 Heures )
X= Counter Mode: 0 Count up and start if MSB of MM set
                  4 Count down
                  8 Count down and start
( Example 59 22 3B 3B 49 -> Set Countdown Timer to 9.59:59 )
59 22 0A 00 80 Sent by ST60 in countdown mode when counted down to 10 Seconds.

61 03 03 00 00 00 Issued by E-80 multifunction display at initialization

65 00 02 Select Fathom (feet/3.33) display units for depth display (see
command 00)

66 00 XY Wind alarm as indicated by flags in XY:
X&8 = 8: Apparent Wind angle low
X&4 = 4: Apparent Wind angle high
X&2 = 2: Apparent Wind speed low
X&1 = 1: Apparent Wind speed high
Y&8 = 8: True Wind angle low
Y&4 = 4: True Wind angle high
Y&2 = 2: True Wind speed low
Y&1 = 1: True Wind speed high (causes Wind-High-Alarm on ST40 Wind
Instrument)
XY =00: End of wind alarm (only sent once)

68 X1 01 00 Alarm acknowledgment keystroke (from ST80 Masterview)
68 X1 03 00 Alarm acknowledgment keystroke (from ST80 Masterview)
68 41 15 00 Alarm acknowledgment keystroke (from ST40 Wind Instrument)
X: 1=Shallow Shallow Water Alarm, 2=Deep Water Alarm, 3=Anchor
Alarm
4=True Wind High Alarm, 5=True Wind Low Alarm, 6=True Wind Angle
high
7=True Wind Angle low, 8=Apparent Wind high Alarm, 9=Apparent
Wind low Alarm
A=Apparent Wind Angle high, B=Apparent Wind Angle low

6C 05 XX XX XX XX XX XX Second equipment-ID datagram (follows 01...), reported
examples:
6C 05 04 BA 20 28 2D 2D ST60 Tridata
6C 05 05 70 99 10 28 2D ST60 Log
6C 05 F3 18 00 26 2D 2D ST80 Masterview

6E 07 00 00 00 00 00 00 00 00 MOB (Man Over Board), (ST80), preceded
by a Waypoint 999 command: 82 A5 40 BF 92 6D 24 DB

70 10 XY Keystroke on Raymarine A25006 ST60 Maxiview Remote Control
X=0 => Single keypress; X=2 => Two keys pressed;
X=4 => Single key: Press,hold&release; X=6 => Two keys:
Press,hold&release
Y=0 => Key 1 "Depth"; Y=1 => Key 2 "Speed" or Keys 1+2;
Y=2 => Key 3 "HDG" or Keys 2+4; Y=3 => Key 4 "Wind" or Keys 1+3;
Y=4 => Keys 3+4 "Nav"

80 00 0X Set Lamp Intensity: X=0 off, X=4: 1, X=8: 2, X=C: 3

81 01 00 00 Sent by course computer during setup when going past USER CAL.
81 00 00 Sent by course computer immediately after above.

82 05 XX xx YY yy ZZ zz Target waypoint name
XX+xx = YY+yy = ZZ+zz = FF (allows error detection)
Takes the last 4 chars of name, assumes upper case only
Char= ASCII-Char - 0x30
XX&0x3F: char1
(YY&0xF)*4+(XX&0xC0)/64: char2
(ZZ&0x3)*16+(YY&0xF0)/16: char3
(ZZ&0xFC)/4: char4
Corresponding NMEA sentences: RMB, APB, BWR, BWC

```

83 07 XX 00 00 00 00 00 80 00 00 Sent by course computer.
 XX = 0 after clearing a failure condition, also sent once after
 power-up.
 XX = 1 failure, auto release error. Repeated once per second.
 XX = 8 failure, drive stopped.

84 U6 VW XY OZ OM RR SS TT Compass heading Autopilot course and
 Rudder position (see also command 9C)
 Compass heading in degrees:
 The two lower bits of U * 90 +
 the six lower bits of VW * 2 +
 number of bits set in the two higher bits of U =
 $(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC ? (U \& 0xC == 0xC ? 2 : 1) : 0)$
 Turning direction:
 Most significant bit of U = 1: Increasing heading, Ship turns
 right
 Most significant bit of U = 0: Decreasing heading, Ship turns
 left
 Autopilot course in degrees:
 The two higher bits of V * 90 + XY / 2
 Z & 0x2 = 0 : Autopilot in Standby-Mode
 Z & 0x2 = 2 : Autopilot in Auto-Mode
 Z & 0x4 = 4 : Autopilot in Vane Mode (WindTrim), requires regular
 "10" datagrams
 Z & 0x8 = 8 : Autopilot in Track Mode
 M: Alarms + audible beeps
 M & 0x04 = 4 : Off course
 M & 0x08 = 8 : Wind Shift
 Rudder position: RR degrees (positive values steer right,
 negative values steer left. Example: 0xFE = 2° left)
 SS & 0x01 : when set, turns off heading display on 600R control.
 SS & 0x02 : always on with 400G
 SS & 0x08 : displays "NO DATA" on 600R
 SS & 0x10 : displays "LARGE XTE" on 600R
 SS & 0x80 : Displays "Auto Rel" on 600R
 TT : Always 0x08 on 400G computer, always 0x05 on 150(G) computer

85 X6 XX VU ZW ZZ YF 00 yf Navigation to waypoint information
 Cross Track Error: XXX/100 nautical miles
 Example: X-track error 2.61nm => 261 dec => 0x105 => X6XX=5_10
 Bearing to destination: $(U \& 0x3) * 90^\circ + WV / 2^\circ$
 Example: GPS course 230°=180+50=2*90 + 0x64/2 => VUZW=42_6
 U&8: U&8 = 8 -> Bearing is true, U&8 = 0 -> Bearing is magnetic
 Distance to destination: Distance 0-9.99nm: ZZZ/100nm, Y & 1 = 1
 Distance >=10.0nm: ZZZ/10 nm, Y & 1 = 0
 Direction to steer: if Y & 4 = 4 Steer right to correct error
 if Y & 4 = 0 Steer left to correct error
 Example: Distance = 5.13nm, steer left: 5.13*100 = 513 = 0x201 =>
 ZW ZZ YF=1_ 20 1_ Distance = 51.3nm, steer left: 51.3*10 = 513 = 0x201 =>
 ZW ZZ YF=1_ 20 0_
 F contains four flags which indicate the available data fields:
 Bit 0 (F & 1): XTE present
 Bit 1 (F & 2): Bearing to destination present
 Bit 2 (F & 4): Range to destination present
 Bit 3 (F & 8): XTE >= 0.3nm
 These bits are used to allow a correct translation from for
 instance an RMB sentence which
 contains only an XTE value, all other fields are empty. Since
 SeaTalk has no special value
 for a data field to indicate a "not present" state, these
 flags are used to indicate the
 presence of a value.
 In case of a waypoint change, sentence 85, indicating the new
 bearing and distance,
 should be transmitted prior to sentence 82 (which indicates the
 waypoint change).
 Corresponding NMEA sentences: RMB, APB, BWR, BWC, XTE

86	X1	YY	yy	Keystroke	
				X=1: Sent by Z101 remote control to increment/decrement	
				course of autopilot	
	11	05	FA	-1	
	11	06	F9	-10	
	11	07	F8	+1	
	11	08	F7	+10	
	11	20	DF	+1 & -1	
	11	21	DE	-1 & -10	
	11	22	DD	+1 & +10	
	11	28	D7	+10 & -10	
	11	45	BA	-1	pressed longer than 1 second
	11	46	B9	-10	pressed longer than 1 second
	11	47	B8	+1	pressed longer than 1 second
	11	48	B7	+10	pressed longer than 1 second
	11	60	DF	+1 & -1	pressed longer than 1 second
	11	61	9E	-1 & -10	pressed longer than 1 second
	11	62	9D	+1 & +10	pressed longer than 1 second
	11	64	9B	+10 & -10	pressed longer than 1 second (why not 11 68 97 ?)
				Sent by autopilot (X=0: ST 1000+, X=2: ST4000+ or ST600R)	
	X1	01	FE	Auto	
	X1	02	FD	Standby	
	X1	03	FC	Track	
	X1	04	FB	disp (in display mode or page in auto chapter = advance)	
	X1	05	FA	-1 (in auto mode)	
	X1	06	F9	-10 (in auto mode)	
	X1	07	F8	+1 (in auto mode)	
	X1	08	F7	+10 (in auto mode)	
	X1	09	F6	-1 (in resp or rudder gain mode)	
	X1	0A	F5	+1 (in resp or rudder gain mode)	
	X1	21	DE	-1 & -10 (port tack, doesn't work on ST600R?)	
	X1	22	DD	+1 & +10 (stb tack)	
	X1	23	DC	Standby & Auto (wind mode)	
	X1	28	D7	+10 & -10 (in auto mode)	
	X1	2E	D1	+1 & -1 (Response Display)	
	X1	41	BE	Auto pressed longer	
	X1	42	BD	Standby pressed longer	
	X1	43	BC	Track pressed longer	
	X1	44	BB	Disp pressed longer	
	X1	45	BA	-1 pressed longer (in auto mode)	
	X1	46	B9	-10 pressed longer (in auto mode)	
	X1	47	B8	+1 pressed longer (in auto mode)	
	X1	48	B7	+10 pressed longer (in auto mode)	
	X1	63	9C	Standby & Auto pressed longer (previous wind angle)	
	X1	68	97	+10 & -10 pressed longer (in auto mode)	
	X1	6E	91	+1 & -1 pressed longer (Rudder Gain Display)	
	X1	80	7F	-1 pressed (repeated 1x per second)	
	X1	81	7E	+1 pressed (repeated 1x per second)	
	X1	82	7D	-10 pressed (repeated 1x per second)	
	X1	83	7C	+10 pressed (repeated 1x per second)	
	X1	84	7B	+1, -1, +10 or -10 released	
87	00	0X		Set Response level	
				X=1 Response level 1: Automatic Deadband	
				X=2 Response level 2: Minimum Deadband	
88	03	WW	XX	YY	ZZ
					Autopilot Parameter: Sent by AP every
					second while in parameter setting mode.
					(User or Dealer Calibration Mode)
					WW Parameter Number
					XX Current Setting
					YY Max Parameter Value
					ZZ Min Parameter Value
					Known Paramters: Parameter (min-max) [default]
Number					rudder gain (1-9) [2]
1					counter rudder (1-9) [2]

2 rudder limit (10-40) [30]
 3 turn rate limit (1-30) [off]
 4 speed (4-60) [8]
 5 off course limit (15-40) [20]
 6 auto trim (0-4) [1]
 7 power steer [Joy Stick] ON/OFF (not on new 400G)
 9 drive type (3,4,5) [3]
 A rudder damping (1-9) [2]
 B variation: (full degrees)(-30 to +30) [0]
 C auto adapt: 0=Off,1=North,2=South [1]
 D auto adapt latitude (0-80) [0]
 E auto release (only for stern drive) ON/OFF
 F rudder alignment (-7 to +7) [0]
 10 Wind Trim (Wind Response) (1-9) [5] (only for sail)
 11 Response (1-9) [5]
 12 Boat type:1=displ,2=semi-displ,3=plan,4=stern,5=work,6=sail
 13 Cal Lock: 0=OFF, 1=ON [0]
 15 Auto Tack Angle (40-125) [100] (only for sail)
 1d

89 U2 VW XY 2Z Compass heading sent by ST40 compass instrument
 (it is read as a compass heading by the ST1000(+) or ST2000(+)
 autopilot)

Compass heading in degrees:

The two lower bits of U * 90 +

the six lower bits of VW * 2 +

the two higher bits of U / 2 =

$(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC) / 8$

Locked stear reference (only send by the ST40 compass):

The two higher bits of V * 90 + XY / 2

Z & 0x2 = 0 : St40 in Standby mode

Z & 0x2 = 2 : St40 in Locked stear mode

Corresponding NMEA sentences: HDM, HDG, HDT, VHW

90 00 XX Device Indentification
 XX=02 sent by ST600R ~every 2 secs
 XX=05 sent by type 150, 150G and 400G course computer
 XX=A3 sent by NMEA <-> SeaTalk bridge ~every 10 secs

91 00 0X Set Rudder gain to X

92 02 XX YY 00 Set Autopilot Parameter: Sent by the remote head
 (e.g. ST600R) to set a particular parameter.
 XX Parameter Number (see 88)
 YY Value to set to.

93 00 00 Enter AP-Setup: Sent by course computer before
 finally entering the dealer setup. It is repeated
 once per second, and times out after ten seconds.
 While this is being sent, command 86 X1 68 97 is
 needed for final entry into Setup. (600R generates

this when -1 & +1 are pressed simultaneously in this mode).

95 U6 VW XY OZ 00 RR 00 0T Replaces command 84 while autopilot is in value setting mode

e.g. lamp intensity or response level

99 00 XX

Compass variation sent by ST40 compass instrument or ST1000, ST2000, ST4000+, E-80 every 10 seconds but only if the variation is set on the instrument
Positive XX values: Variation West, Negative XX values:

Variation East

Examples (XX => variation): 00 => 0, 01 => -1 west, 02 => -2

west ...

FF => +1 east, FE => +2 east ...

Corresponding NMEA sentences: RMC, HDG

9A 09 L11 L12 L13 L14 L21 L22 L23 00 00 00 Version String:

L11 means line 1 char 1. There are two lines, line 1

Can have 4 characters and line two can have 3

Characters. Char: "A"= 0x00, "B"= 0x01,.....

Char: "0"= 0x25, "1"= 0x26,

Some special characters are mapped to the range

Between alphas and numeric chars. It seems modulo

masked at 0x36, and wraps around from there.

9C U1 VW RR Compass heading and Rudder position (see also command 84)

Compass heading in degrees:

The two lower bits of U * 90 +

the six lower bits of VW * 2 +

number of bits set in the two higher bits of U =

$(U \& 0x3) * 90 + (VW \& 0x3F) * 2 + (U \& 0xC ? (U \& 0xC == 0xC ?$

2 : 1): 0)

Turning direction:

Most significant bit of U = 1: Increasing heading, Ship turns

right

Most significant bit of U = 0: Decreasing heading, Ship turns

left

Rudder position: RR degrees (positive values steer right,

negative values steer left. Example: 0xFE = 2° left)

The rudder angle bar on the ST600R uses this record

9E FC 49 49 03 XX AA BB YY OO PP GG HH II JJ Waypoint definition

XX: Degrees LAT, YY: Degrees LON

min&sec LAT= AA+(BB&0x1F)*256, BB&0x80 = 0: North, BB&0x80 = 0x80:

South

min&sec LON= OO+(PP&0x1F)*256, PP&0x80 = 0: West, PP&0x80 = 0x80:

East

GG HH II JJ: Last four characters of waypoint name

A1 XD 49 49 GG HH II JJ C1 C2 C3 C4 C5 C6 C7 C8 Destination Waypoint Info

GG HH II JJ: Last four characters of waypoint name

C1...C8: Up to 8 characters of WP name, unused are 0

Longer names (> 8 chars) create an additional record:

X=0: single record (short name)

X=1: 1st record, more follows

X=3: last record

Corresponding NMEA sentences: RMB, APB, BWR, BWC

A2 X4 00 WW XX YY ZZ Arrival Info

X&0x2=Arrival perpendicular passed, X&0x4=Arrival circle entered

WW,XX,YY,ZZ = Ascii char's of waypoint id. (0..9,A..Z)

Takes the last 4 chars of name, assumes upper case

only

Corresponding NMEA sentences: APB, AAM

A4 02 00 00 00 Broadcast query to identify all devices on the bus, issued e.g. by C70 plotter

A4 06 00 00 00 00 00 Termination of request for device identification, sent e.g.

by C70 plotter

A4 12 II VV WW Device answers identification request
 II: Unit ID (01=Depth, 02=Speed, 03=Multi, 04=Tridata,
 05=Tridata repeater, 06=Wind, 07=WGM, 08=Navdata GPS, 09=Maxview,
 0A=Steering compas, 0B=Wind Trim, 0C=Speed trim, 0D=Seatalk GPS,
 0E=Seatalk radar ST50, 0F=Rudder angle indicator, 10=ST30 wind, 11=ST30
 bidata, 12=ST30 speed, 13=ST30 depth, 14=LCD navcenter, 15=Apelco LCD
 chartplotter, 16=Analog speedtrim, 17=Analog depth, 18=ST30
 compas, 19=ST50 NMEA bridge, A8=ST80 Masterview)
 VV: Main Software Version
 WW: Minor Software Version

A5 GPS and DGPS Info
 A5 57 QQ HH ?? AA GG ZZ YY DD GPS and DGPS Fix Info
 Signal Quality= QQ&0xF, QQ&0x10: Signal Quality available flag
 HDOP= HH&0x7C, HH&0x80: HDOP available flag
 Antenna Height= AA
 Number of Sats= (QQ&0xE0)/16+(HH&0x1), HH&0x2: NumSats available
 flag
 GeoSeperation= GG*16 (-2048...+2047 meters)
 Differential age=(ZZ&0xE0)/2+(YY&0xF), YY&0x10: Diff. age
 available flag
 Differential Station ID=(YY&0xC0)*4+DD, YY&0x20: Diff.St.ID
 available flag
 Corresponding NMEA sentences: GGA, RMC, GSV, GLL, GGA
 , A5 8D ..., A5 98 ..., A5 B5 ..., A5 0C... Unknown meaning
 A5 74 ID ID ID ID GPS Info: ID numbers of satellites
 A5 XD NN AA EE SS MM BB FF GG OO CC DD XX YY ZZ GPS Info: Sat Position and
 Signal
 Data of up to three sattelites [1,2,3] per datagram
 Satellite number: [1] NN&0xFE, [2] (MM&0x70)/2+(BB&0x7), [3]
 CC&0x3F
 Satellite azimuth:[1] AA*2+(EE&0x1), [2] (BB&0xF8)*2+(FF&0xF), [3]
 (CC&0xC0)*2+DD&0x7F
 Satellite elevation:[1] (EE&0xFE)/2, [2] (FF&0xF0)/2+GG&0x7, [3]
 XX&0x7F
 Satellite signal: [1] (SS&0xFE)/2, [2] (GG&0x80)/2+OO&0x3F, [3]
 (YY&0xFC)/2+ZZ&0x1

It seems that there will be 4 sat info datagrams generated, the first with X=0 carries the position and signal data of the 1st 3 satellites. The second also with X=0, but NN&0x1 set and a length of 0x0C carries the data of the next 2 satellites and then the ID numbers of the 1st 4 sats. A datagram like the 1st one, but with X=2 carries data of 3 more sats [6,7,8]. It was not possible to get more than 8 sats mapped to SeaTalk. Finally a datagram with X=7 carries the next 5 ID numbers.

Corresponding NMEA sentences: GSV, GSA

A7 09 86 000000000000000079 Unknown meaning, sent by Raystar 120 GPS
 A8 53 80 00 00 D3 Alarm ON for Guard #1 or #2
 A8 43 80 00 00 C3 Alarm OFF for Guard #1 or #2
 AB 53 80 00 00 D3 Alarm ON for Guard #1 or #2
 AB 43 80 00 00 C3 Alarm OFF for Guard #1 or #2


[Return to Top of Page](#) [Overview](#) [Part 1](#) [Part 3](#)

Navigation: [Home](#) => [Profil](#) => [SeaTalk](#) => Part3
Stand: 01.09.2003

SeaTalk Technical Reference Part 3: Processing SeaTalk Data with a PC


Unidirectional SeaTalk => RS232 Interface

This simple unidirectional interface circuit inverts the SeaTalk signal to make it readable by the PC serial port:



Bidirectional SeaTalk <=> RS232 Interface

For bidirectional communication the circuit has to be extended by a second transistor:



A PC-board may be obtained from [Frank Wallenwein](#).

SeaTalk Monitor

The following piece of C-code gives an example of how to collect and process SeaTalk data. It monitors the SeaTalk bus and echoes the SeaTalk datagrams in hexadecimal notation to the screen.

```
#include <stdio.h>

/* Set Address of Serial Port: COM1=0x3F8, COM2=0x2F8 */
#define PORT 0x3F8

unsigned int collision_ctr, overrun_ctr;
char buffer[256], in_ptr, out_ptr, limit_ptr;
char line_status_reg, receiver_buf, byte_ctr;
char hex[]="0123456789ABCDEF";

main() {
    puts("SeaTalk Monitor Rev. 1.01      (c)2000 by Thomas Knauf\r\n");

    /* Serial Port Initialization */
    _outb( 0, PORT+1); /*IER Disable Interrupts */
    _outb( 1, PORT+2); /*FCR Enable Fifo */
    _outb(0x80, PORT+3); /*LCR Enable access to Divisor Latch */
    _outb( 24, PORT ); /*DLL Set Baud Rate to 4800 LSB*/
    _outb( 0, PORT+1); /*DLM Baud Rate Divisor MSB */
    _outb(0x3B, PORT+3); /*LCR Stick Parity to 0, Enable Parity, 1 Stop bit, 8 bits/char
*/
    _outb(0x0F, PORT+4); /*MCR Disable LOOP Mode */
    _outb( 0, PORT+5); /*LSR Clear Error flags */

    while(1) { /* Continous data processing loop */
        if((line_status_reg= _inb(PORT+5)) & 1) { /* LSR New SeaTalk Data received ? */
            receiver_buf=_inb(PORT); /* RBR Read SeaTalk Data Byte */
            if(line_status_reg & 2) overrun_ctr++; /* PC too slow, should not happen */
            if(line_status_reg & 4) { /* Parity bit set => Command Byte */
                if(byte_ctr) { /* More characters expected => Collision */
                    in_ptr=limit_ptr; /* Discard last datagram, restart from beginning */
                    collision_ctr++; /* Count collision events */
                }
                buffer[in_ptr++]='\r'; /* Put new command on new line */
                buffer[in_ptr++]='\n';
                byte_ctr=255; /* Undefined datagram length, wait for next character
*/
            }
            else
                if(byte_ctr==254) /* Attribute byte ? */
                    byte_ctr=(receiver_buf & 0xF) + 2; /* Read expected datagram length */
            if(byte_ctr) { /* Process valid data bytes, should always be true */
                buffer[in_ptr++]=hex[receiver_buf >> 4]; /* Convert Data to hex */
                buffer[in_ptr++]=hex[receiver_buf & 0xF];
                buffer[in_ptr++]=' '; /* Seperate by space */
                if(! --byte_ctr) limit_ptr=in_ptr; /* Complete datagram ready for
output */
            }
        }
        else
            if(out_ptr != limit_ptr) /* Characters waiting for Output ? */
                putchar(buffer[out_ptr++], stdout); /* Copy single character from buffer to screen
*/
            else if(scr_csts()) break; /* Query keyboard, terminate if any key hit */
    }
    printf("\r\nSeatalk Collisions : %5u", collision_ctr);
    printf("\r\nUART Overrun Errors: %5u", overrun_ctr);
}
```

Compiled EXE-Files can be downloaded here as [SEAMON1.EXE](#) (using COM1:) or [SEAMON2.EXE](#) (using COM2:). They run in any MS-DOS environment. Redirecting the output logs data to a file (example: SEAMON1 > LOGFILE). Pressing any key terminates the program.

SeaTrack: Route documentation software

The [SeaTrack](#) software developed by Philip Beekman for reading editing combining displaying and saving trip routes is able to handle SeaTalk data directly. The author also describes how he solved the problem to handle the [parity/command-bit interpretation within VisualBasic](#).

SeaSigma: A simple SeaTalk command generator

The file [SeaSigma.zip](#) contains a MS-Windows program which allows to generate SeaTalk commands and to send them via COM1: or COM2: to the SeaTalk bus. Since SeaSigma is a contribution of [Ales Janhar](#) I cannot give support or take any responsibility for this software.

[Return to Top of Page](#) [Overview](#) [Part 1](#) [Part 2](#)

Reading SeaTalk data using Microsoft Communications Control in VisualBasic

On the website of Thomas Knauf (<http://www.thomasknauf.de/seatalk.htm>), the details of the SeaTalk protocol are discussed, and also the interface with a PC. Based on this information it is possible to read and process Seataalk input data in VisualBasic, using the Microsoft Communications Control. The advantage is obvious: we can directly interpret the SeaTalk input, and display the data on our Computer Navigation Centre. Below, we discuss how this is accomplished.

The practice of SeaTalk to set the parity bit, in order to signal a new datagram, is not the same as creating a parity condition in regular data transmission. Normally, the number of bits set in a byte is counted, and the parity bit is set to make the total bits even or odd (depending on the parity setting, see <http://support.microsoft.com/default.aspx?scid=kb;en-us;52196> for an explanation). A further complication may be, that the after the parity event is raised by the Communications Control, when characters continue to be received, the parity event may be raised again. But if there is more than one character in the input buffer, it is not clear which character raised the parity condition.

As a workaround we will process the parity event as soon as it is raised, and then quickly process all remaining characters in the buffer, assuming these caused no parity. In my experience, this works quite well, creating less than a few percent wrong incorrect receptions.

The code example (**SeaTalkTest.vbp**) provided in attached zip file demonstrates this approach. It employs three key functions:

Public Function SetSeaTalkCom(myPort As Integer, myCom As MSComm) As Boolean

Opens the input port (**myPort**) using the Communications Control (**myCom**), with the proper settings:

.Settings = "4800,S,8,1"	4800 baud, Space, 8 data, and 1 stop bit.
.ParityReplace = ""	Parity will be detected by OnComm event, character will still be used
.InputMode = comInputModeBinary	Expect also Hex 00 characters, and process data as a binary array, not as a text string
.Handshaking = comNone	SeaTalk has no handshaking
.InputLen = 1	We will process One character at a time
.RThreshold = 1	We will react when we get the character

Public Sub MSCommSeaTalkChar(myComm As MSComm, SeaTalkMode As Integer, mymsg As String, myMsgNum As Integer, Optional myInp As String)

Called by myComm_OnComm whenever a Communication event is raised on MsComm. It processes and stores the parity event, if received, and if called in a receive condition processes any characters available in the input buffer.

MyComm	the Communications Control we are using
SeaTalkMode	Public Const SeaTalkModeBoat = 1 (look at parity bit and parity algorithm) Public Const SeaTalkModeSim = 2 (only look at parity bit)
myMsg	will contain the message received, if a complete message was received
myMsgNum	will contain the SeaTalk message number of above
myInp	hex representation of any input bytes received will be appended to this string, if provided

Function DoSeaTalkMessage(b() As Byte) As String

When we have a full SeaTalk Message in our input buffer array (b()), we call this function to process

the message. It returns a legible string.

Notice

Although this code has demonstrated to work in my case (Pentium processor, Windows XP, three instruments on SeaTalk bus), no guarantees can be given. Also from time to time we detect improvements, which are implemented without notice. Any suggestions are welcome at : 'zee "@" pbeekman.com' (replace ' ' ' by '@' for spam protection)

Downloads:

- [seatalktestp.zip](#) this documentation + vb project
- [seatalktestc.zip](#) complete setup package for executable
- [seatalktestx.zip](#) executable only

This page is available from: <http://pbeekman.com/seatalk>

Also take a look at look at <http://pbeekman.com/seatrack.htm>, which can be used to process seatalk input directly as well.

Thomas Knauf website on Seatalk: <http://www.thomasknauf.de/seatalk.htm>

Raymarine: <http://raymarine.com>

Microsoft knowledgebase on parity: <http://support.microsoft.com/default.aspx?scid=kb;en-us;52196>